




COMMAND CENTER BUYER'S GUIDE

What you need to have to use COMMAND Center.

1) Sensors

Every project will need COMMAND Center Sensors. Sensors start at \$35 and come in a variety of standard lengths. Customized lengths are also available. The number of sensors you need depends on your project.

 <p>COMMAND Center Sensor</p>	• Temperature/maturity sensor with 4 ft (1.22 m) lead wire	\$35
	• Temperature/maturity sensor with 8 ft (2.44 m) lead wire	\$37
	• Temperature/maturity sensor with 15 ft (4.57 m) lead wire	\$40
	• Temperature/maturity sensor with 30 ft (9.14 m) lead wire	\$50
	• Temperature/maturity sensor with 50 ft (15.24 m) lead wire	\$58
	• Temperature/maturity sensor with custom length lead wire	Varies

2) Software

Every purchase includes the powerful COMMAND Center software free of charge. Software files are compatible across readers, so you can use any combination seamlessly.


3) Your preferred reader

Retrieve data from COMMAND Center Sensors using **any** of the following options:

IOS DEVICE

Most popular option

Use with iPhone, iPod, or iPad.




Accessory required:



SENSOR READER MODULE (SRM)
\$99

SRM is reusable and connects to multiple sensors. Minimum of one required per project.

WINDOWS DEVICE



Accessory required:

USB DOWNLOAD CABLE
\$75

OR

SERIAL DOWNLOAD CABLE
\$55

Use with Windows PC, laptop, or tablet.

Use with handheld PC or Trimble Nomad.

GET COMMAND CENTER TODAY

To learn more about how COMMAND Center can accelerate schedules and cut costs on your next construction project, visit www.COMMANDCenterConcrete.com or call +1 (888) 451 6233.



Connect with us.



Proudly assembled in the USA.

